














# Handwheels for hydraulic controls

on-off and proportional valves

	OPTIONS CODES AND DIMENSIONS	FEATURES	VALVE TYPE
OPTION	<p><b>IV</b></p> 	Regulating handwheel	ARE, SP-CART ARE, SP-CART M-6, ARAM, AGAM, REM, AGIR, AGIS, AGIU, HMP, HM, KM, HS, KS, HG, KG, LIMM, LIRA, LICM
OPTION	<p><b>IVF</b></p> 	Regulating knob	ARE, SP-CART ARE, SP-CART M-6, AGIS, AGIU (as spare part, code VFG instead of VF and VSG instead of VS), HMP, HS, HG.
OPTION	<p><b>IVS</b></p> 	Manual override with safety locking. Regulation possible only with pushed knob.	HMP, HS, HG.
OPTION	<p><b>IVP</b></p> 	Prolonged manual override protected by rubber cap	DHI, DHU, DHO, DKE, DKER, DLOH, DLOK, DPHI, DPHU, DPHO, LID The option /WP is standard for DHO, DPHO
SPARE PART	<p><b>SP-WPD/H (size 06)</b></p> 	Manual override with detent, for mechanical operation and fixed actuation of spools	DHI, DHU
SPARE PART	<p><b>SP-WPD/KER-DC</b></p> 		DKER-DC

	OPTIONS CODES AND DIMENSIONS	FEATURES	VALVE TYPE
SPARE PART	<p><b>SP-WPD/Z</b></p> 	Manual override with detent, for mechanical operation and fixed actuation of spools. Only for open-loop valves.	DHZO, DKZOR, DPZO, QVHZO, QVKZOR
OPTION	<p><b>/K</b></p> 	Lock key for the setting knob	DHQ, DKQ QV-06,
OPTION	<p><b>/K</b></p> 		QV-10/2, QV-20/2 LIQV
OPTION	<p><b>/G</b></p> 	Adjustment by graduated micrometer	HQ, KQ, JPQ-2
OPTION	<p><b>/G</b></p> 		JPQ-3
OPTION	<p><b>/N</b></p>  <p>size 06                      size 10</p>	Manual micrometric adjustment	DHZO, DKZOR QVHZO, QVKZOR
OPTION	<p><b>/NV</b></p>  <p>size 06                      size 10</p>		